

KM-1635




The KM-1635 uses an **electronic counter** to record the meter readings. This can be viewed on the Operator Panel or printed out in a report.

Use the following steps to view the electronic meter reading or print out the report.

STEP 1 Press the **STOP/CLEAR** button for 3 seconds. The Copy Count will be displayed on the message display.

STEP 2 Pressing on the **START** button while the Copy Count is displayed will output the Counter Report.



==== COUNTER REPORT ====				
--- Meter No. # 30000000 ---				
-Total count- 883				
-Output count-				
#	Copy	Fixtime	Total	
0/100	200	8830	883	
-Scan count-				
#	Copy			
0/000000	10			

STEP 3 The copier will return to normal Copy mode after the Copy Count has been displayed.