


KM-2030




The KM-1530 and KM-2030 copiers use a **mechanical counter** located on the right hand side of the machine just above and forward of the Power Switch.

Your meter reading is taken directly from this counter.


The KM-2030 can also produce a **Counter Report** providing information on the number pages printed and the average toner density. To print out this report please follow the steps below;

STEP 1 Press the * / Language key on the Operator Panel. The indicator light above the Language key should illuminate

The management mode selection screen will appear on the LCD display.




STEP 2 Press the DOWN ARROW key under the LCD Panel and select **MACHINE DEFAULT**. Press the **ENTER** key to select.



STEP 3 Enter your Management "ID-CODE" "2000" with the numeric keys



STEP 4 Press the DOWN ARROW key under the LCD Panel and select **COUNTER REPORT**. Press the **ENTER** key to print out the report.



STEP 5 The Toner Counter Report is printed. After printing is finished the display will return to the screen in STEP 1. Press the * / Language button to return to normal copier operations.