


KM-3050



The KM-3050 / 4050 and 5050 use an **electronic counter** to record the copy counts. This can be read off the LCD display or printed out in a report.


Use the following steps to check the electronic copy count or print the report.

STEP 1 Press the Counter button on the Operator Panel.



STEP 2 Read the TOTAL PRINTED PAGES from the top of the screen.

STEP 3 To print the report press the **Print Status Page** button on the LCD display.



STEP 4 Press the **CLOSE** button on the display to return to normal copy mode.