

## KM-3530




The KM-2530, KM-3530 and KM-4030 copiers use a **mechanical counter** located on the right hand side of the copier. Your meter reading is taken directly from this counter.

You can also print a **Counter Report** providing information on the number pages printed and the average toner density. To print out this report please follow the steps below;


**STEP 1** Press the **\*/ Default Setting** key on the control panel. The Default Setting menu will appear on the main LCD display.



**STEP 2** Press the **Print Form** key on the touch screen.




**STEP 3** Enter your Administrator Code  
**"2500"** for the KM-2530  
**"3500"** for the KM-3530  
**"4000"** for the KM-4030




*NB: These are the*

*default values but  
may have been  
changed by the Key  
Operator /  
Administrator.*

**STEP 4** Press the **Counter Report** key on the touch screen in the Print Report Menu.



The message "Now Copying" will appear and the report will be printed out.



**STEP 5** Press the **CLOSE** key on the touch screen to return to the "Default Settings" menu. Press the **CLOSE** key again to return to normal COPY mode.