

## KM-5035




The KM-3035 / 4035 and 5035 use an **electronic counter** to record the copy counts. This can be read off the LCD display or printed out in a report.

Use the following steps to check the electronic copy count or print the report.

- STEP 1** Press the **Default Setting / Counter** button on the Operator Panel.  
*NB: On some models the caption above the button will display Default Setting / Counter, not \* as shown in the photo on the right. The Default Setting screen will appear on the display.*



- STEP 2** Press the **Counter Check** button on the touch display. The total number of copies will be displayed.



- STEP 3** To print the Counter Report press the **PRINT REPORT** key on the display.



- STEP 4** Press the **CLOSE** key on the touch screen to return to normal COPY mode.

